1

Toughmate G1 X-Strap User Guide



For use exclusively with the Panasonic Toughpad G1 computer

Introduction

Thank you for purchasing a Toughmate series accessory from InfoCase[®]. The Toughmate G1 X-strap compliments your Toughpad G1 Computer by enabling you to comfortably hold your tablet for extended periods of time. Enjoy full tablet functionality while keeping the Toughpad at your side. Removable shoulder strap is included.

 \vee]



Loosen the two Velcro Retention Flaps (#4) on the Top Cuff (#5) of the X-strap. Loosen Velcro Retention Straps Slide the Bottom Cuff (#6) onto the bottom of the Toughpad.

2

3

4

5

Slide the Top Cuff (#5) onto the top of the Toughpad and tighten the Velcro Retention Straps (#4).



With the X-strap secure on your G1, attach the included shoulder strap to two adjacent Shoulder Strap Rings (#3). Your G1 is ready to be carried in portrait or landscape orientation.

🗊 InfoCase®

Tips for Use

- 1. For maximum retention, be sure to attach the included Velcro strips on your G1 in the three locations shown on page two of this user guide.
- 2. Ensure the Velcro Retention Straps (#4) are tightly secured before transporting your Toughpad.

Optional User Harness Accessory

Need hands free access while using your G1? The Toughmate User Harness accessory is the perfect compliment for your Toughmate G1 X-strap (Part number: *TBCUSHARN-P*. Visit our website: *www.infocase.com* or scan QR code below to learn more or purchase this accessory.



Warranty

InfoCase products are dynamic, consistently improved and reinvented to bring you the best products on the market. We use only the highest quality materials to meet your mobile technology demands.

InfoCase offers a 1 year limited warranty on defects and workmanship on your Toughmate accessory. Please visit:

http://www.InfoCase.com/warranty.php or call 1-800-248-4844 to obtain more information on the InfoCase warranty.