

Fieldmate ZX70 Always On User Guide

For use with Getac ZX70



Introduction

Thank you for purchasing a Fieldmate® Always-On series case from InfoCase®. Your case will provide added full-time protection and increased productivity while using your Getac ZX70.

Features



Installation

1

Loosen the Hand Strap (1), Velcro Straps (2), and Tri Glide Retention Strap and slide your Getac ZX70 into the case at an angle. Once the tablet is in place, feed the Hand Strap (1) and Velcro Straps (2) through the appropriate webbing glides.

**2**

While gently but firmly holding the ZX70 in place, pull the Velcro Strap (2) until the back of the case is tight against the ZX70. Then press the tabs down to secure the Velcro.

To remove your ZX70, simply release the Velcro, loosen the tabs and hand strap, and carefully remove the tablet.

Tri Glide Retention Strap

3

The tri glide retention strap (5) will feed through the appropriate glide located on the back of the case. For optimal retention, feed the strap back through the glide, the strap will be facing outward as shown below.



O-Ring and Shoulder Strap

4

The included shoulder strap (7) will clip to the O-Rings (6). When using the shoulder strap, keep your ZX70 screen in, in order to protect the screen from scratching.



Easel

5

The easel can be extended out to be used in a viewing mode. When not in use, the easel can be flattened and secured via Velcro.



Tips for Use



The Always On style case can be carried in a landscape orientation using the included Shoulder Strap (7). Simply clip the strap to the two O-Rings (6).

The Always On style case has openings for the most important buttons and ports. Care should be taken to protect the openings from rain or other liquids to avoid damage to your Getac ZX70.

Warranty

InfoCase products are dynamic, consistently improved and reinvented to bring you the best products on the market. We use only the highest quality materials to meet your mobile technology demands.

InfoCase offers a warranty on defects and workmanship on this product. Please visit: <http://www.InfoCase.com/warranty> or call 1-800-248-4844 to obtain more information on the InfoCase warranty.