

Toughmate™


TOUGHBOOK G2 Tablet Moduflex User Guide



Introduction

The Moduflex style case is designed to be used with the TOUGHBOOK G2 in a variety of ways to help ease in transportation and increased productivity. Features include easel functionality, a shoulder strap, and a hand strap.

Features




Installation

Note: Before installation, please ensure that the TOUGHBOOK G2 device is laid face down on a soft surface.

1

Carefully center the Moduflex onto the back of the G2, aligning the retention straps (1) with the slot openings found on the device.



Once in place, feed the retention straps (1) into the slots.

2

Note: For use of optional accessories, add loose O-Rings (6) onto the two left retention straps (1).



3

Loop the Retention Straps (1) back through the webbing glides. Tighten all four straps through the webbing glides to ensure an even and secure fit. To secure each retention strap, feed the straps through the webbing glides a second time and tighten each strap securely.



4

For ease of install, unbuckle both Quick Connect Clips (2). Next, feed the Retention Straps (1) back through each webbing glide a third time as shown. Once all four are complete, connect both Quick Connect Clips (2). Warning: For a secure connection to be created, the Webbing Straps must loop through the glide three times as shown.



Tips for Use

The Moduflex style case includes a built in hand strap (4) which includes a stylus loop (5).



The included shoulder strap (7) can be attached to the top two O-Rings (6) and can be carried in landscape orientation. A user harness (sold separately) can also connect to all 4 O-rings (6).



To access the batteries and gadgets while the Moduflex case is installed, simply release the two quick connect clips (2) and lift up the back of the Moduflex for access. Once finished, connect both quick connect clips (2).



To use the easel stand (3), simply unfold the easel stand from the Velcro and position on a flat secure surface. Once finished, simply push the easel stand (3) back into the Velcro on the back of the Moduflex.



Note: While the G2 Tablet Moduflex is installed, it will not be compatible with tablet mode vehicle docks.

Warranty

InfoCase products are dynamic, consistently improved and reinvented to bring you the best products on the market. We use only the highest quality materials to meet your mobile technology demands.

InfoCase offers a warranty on defects and workmanship on this product. Please visit: <http://www.InfoCase.com/warranty> or call 1-800-248-4844 to obtain more information on the InfoCase warranty.