

TOUGHBOOK G2 Mobility Bundle User Guide



Introduction

Your Mobility Bundle is designed to provide ease in transportation for the TOUGHBOOK G2 using the hand strap and shoulder strap.

Features



Installation

Note: Before installation, please ensure that the TOUGHBOOK FZ-G2 is separated from the keyboard and laid face down on a soft flat surface.

Warning: Only attach mobility bundle in landscape position, do NOT attach in a portrait position (see page 4 for details.)

1

To start install the G2 Anchors (4), they will be positioned on either the top two or bottom two G2 connection points (depending on if you want your screen top or bottom facing). **NOTE: Once the G2 Anchors (4) are installed, they cannot be removed. Please choose carefully.** Hold each Anchor carefully into position and firmly press down until a click is heard. Once installed, the clip will be flush with your device as shown in the images above. If the clip is not flush, remove the clips and rotate them so that they fit flush and correct. Note: When installing at the top side of the device, make sure the Anchors are installed straight down to prevent interference with adjacent surfaces. **Please ensure the Anchors are fitted correctly before proceeding.**



2



Feed each of the Nylon Webbing Straps (3) into the corresponding openings (on either the D-Ring Kit or G2 Anchors). Next, loop the webbing back around and feed the webbing into the Webbing Glides (2) as shown.

3



After tightening down the webbing, loop the Nylon Webbing Strap (3) back into the Webbing Glide (2) for a second time and tighten. Next, loop the webbing back into the Webbing Glide (2) for a third time as shown above.

4

To finish installation, pull the D-Ring (1) and the Nylon Webbing Strap (3) until fully tightened as shown.

Warning: For a secure connection to be created, the Nylon Webbing Straps (3) must loop through the Webbing Glides (2) all three times as shown.



5



When both straps are installed, the included Ergonomic Handle (5) and Shoulder Strap (6) can be clipped into place on the D-Rings (1) (as shown in the image.)

Tips For Use

1. The included Shoulder Strap (6) is adjustable via a Webbing Glide located near the end of the strap.
2. The Webbing Glides (2) should be tightened down as much as possible to ensure a tight connection.
3. The Mobility Bundle is designed to be small and out of the way so it can remain on your device at all times.
4. **Warning: Only attach mobility bundle in landscape position. Do NOT attach in portrait position (as shown in image).**
5. **Warning: The G2 Mobility Bundle is intended for tablet only. Do NOT attach the G2 Keyboard while using the Mobility Bundle.**



Warranty

InfoCase products are dynamic, consistently improved and reinvented to bring you the best products on the market. We use only the highest quality materials to meet your mobile technology demands.

InfoCase offers a warranty on defects and workmanship on this product. Please visit: <http://www.InfoCase.com/warranty> or call 1-800-248-4844 to obtain more information on the InfoCase warranty.