

Smartphone Forearm Cradle for OtterBox uniVERSE User Guide



Introduction

The OtterBox uniVERSE arm mount cradle for smart phones is designed to help increase productivity and help with the ease of use. With adjustable straps, the device can comfortably fit on most arms and always in reach.

FM-RMCRDL-UNI 1

Features



Installation

Start by placing the (1)
Cradle face down. Both the
(2) "Front" Short Strap and
(3) "Back" Long Strap will
be placed Velcro side down
as shown in the image. As
seen in "Features", ensure
that the (2) "Front" Short
Strap will feed through the
slots near the top side of
the cradle while the (3)
"Back" Long Strap will feed
through the slots near the



"Back" Long Strap will feed through the slots near the bottom side of the cradle.

Feed the straps through the bottom slots. Once the label

Feed the straps through the bottom slots. Once the label tags are though the bottom slots, feed the strap back up through the top slots as shown in the image. Note: Before proceeding, ensure that the strap tags are in the slot, within the cradle as shown in the image.



The straps will now feed through the slots on opposite side of the cradle. Feed the straps into the top slots until the strap sits flat against the cradle. Next, feed the strap through the bottom slots as shown in the image.



Feed the ends of the straps back through their corresponding glide loop. Press the hook Velcro against the loop Velcro. The device is now ready for installation.



The OtterBox uniVERSE case with device will slide into the corresponding slotted rail. Gently slide the device down the rail until it stops and snaps gently into place. The device is now installed onto the cradle.



Tips for Use

The arm mount cradle is designed to fit most arm sizes comfortably. While the device is face down on a flat stable surface, slide a hand through the strap loops until the straps and device are located on the desired location on the arm. Tighten each strap so that it fits snugly and firmly against the arm.

WARNING: Do not overtighten the straps, which may lead to a risk of physical discomfort or injury.



This user guide is shown using the OtterBox uniVERSE case for iPhone SE. The Smartphone Forearm Cradle for OtterBox uniVERSE is designed to work with most uniVERSE cases for smart phones. For compatible devices, visit http://www.InfoCase.com for more details.



Warranty

InfoCase products are dynamic, consistently improved and reinvented to bring you the best products on the market. We use only the highest quality materials to meet your mobile technology demands.

InfoCase offers a warranty on defects and workmanship on this product. Please visit: http://www.InfoCase.com/warranty or call 1-800-248-4844 to obtain more information on the InfoCase warranty.

4 © 2024